

DOT TYPE II SAFETY CANS

Provides DOT compliance for over-the-road, air freight, and commercial transport of flammable liquids

- Heavy-duty roll-bars protect the spout from damage during transport to prevent dangerous fuel spillage
- Thumb screw mechanism ensures the filler opening stays closed while being transported
- Flame arresters in both openings are non-sparking for flashback protection
- Self-closing, leakproof lid with nitrile gasket allows pressure relief, automatically venting at 3-5 psi internal pressure to protect against rupture or explosion
- Flexible, 12" long metal spout helps control pouring for safer dispensing
- Ergonomic trigger and handle provide a comfortable grip for easy opening and pouring
- 24-gauge hot-dipped galvanized steel is durable and long-lasting
- Vented steel construction won't shrink or swell with temperature changes
- Deep drawn construction has no top or side seams—double interlock no-weld bottom seam is 100% leak tested
- Accepted under CARB; meet NFPA requirements; meet DOT UN marking 1A1/Y1.2/10



Heavy-duty roll bars protect the spout from damage.



Thumb screw closure ensures filler opening stays closed during transport.



With US and Imported Parts

Capacity	Dimensions (OD x H)	Metal Hose (OD x H)	Approvals / Compliance	Red Models	Yellow Models	CA Prop 65
5 gal (18.9 L)	12.5" x 15.75" (31.8 x 40 cm)	5/8" x 12" (1.6 x cm)	DOT, UN, CARB, NFPA 30	1215SX5	1215SX5Y	⚠
		7/8" x 12" (2.2 x 30.5 cm)		1215	1215Y	⚠

⚠ WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.