



Flammable Waste Drum Safety Cabinets

Starting at
\$2,056.00

Product Images



Short Description

- **Sturdy Construction:** Welded, 18-gauge double-walled steel with 1.5 inches of insulating air space provides excellent fire resistance
- **Clear Identification:** White color and large warning labels clearly identify the cabinet for waste liquid storage
- **Spill Containment:** Reinforced liquid-tight sump contains spills, ensuring safety and compliance
- **Enhanced Safety:** Dual vents with flame arresters and built-in grounding connectors provide additional safety features
- **Convenient Storage:** Half-depth shelf offers additional storage space, accommodating drums with pumps or funnels

- Compliance and Warranty: Meets NFPA and OSHA standards, backed by a ten-year warranty for peace of mind and reliable performance

Description

Justrite Flammable Waste Drum Safety Cabinets are designed for the temporary storage of larger quantities of flammable waste in drums, awaiting pickup and disposal. These cabinets feature a white color that quickly identifies them for waste liquid storage. They include a handy half-depth shelf for additional storage, sized to accommodate drums equipped with pumps or funnels. Constructed from sturdy 18-gauge double-walled, welded steel with 1.5 inches of insulating air space, these cabinets provide excellent fire resistance. They also feature dual vents with flame arresters, four adjustable self-leveling feet, and a built-in grounding connector to prevent static buildup.

To configure your safety cabinet, select from options that meet your specific needs. Choose between storing one or two 55-gallon drums to fit your storage requirements. Additionally, select between manual closing or self-closing doors to ensure compliance with your safety standards. Self-closing doors offer enhanced safety by automatically latching in emergency situations, minimizing human error and ensuring compliance.

Justrite Flammable Waste Drum Safety Cabinets are designed to meet the complex requirements of handling and storing hazardous materials, providing a reliable solution for industries such as laboratories, manufacturing facilities, and chemical processing plants. By configuring your cabinet, you ensure a safe and compliant storage solution tailored to your unique needs. These cabinets come with a ten-year warranty, providing peace of mind and reliable performance.

Specifications

Model No	89-FD
----------	-------

Prop 65

⚠️WARNING:This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Product Options

Capacity:	55 gallon
	110 gallon
Door Style:	Self-close
	Manual

