



Flammable Waste Safety Cabinet

Starting at
\$1,385.00

Product Images



Short Description

- Ideal solution for temporary collection and segregation of waste liquids
- Large warning labels clearly identify contents
- FM-approved
- Ten-year warranty
- Available in 30- and 45-gallon capacities

Description

Justrite Flammable Waste Safety Cabinets are built for the short-term storage and separation of flammable liquid waste, adhering to NFPA and OSHA guidelines. Made with welded, 18-gauge double-walled steel and a 1-1/2 inch air gap for insulation, these cabinets offer strong fire protection. They include adjustable shelves that channel spills into a sealed bottom area, double vents with built-in flame barriers, grounding connections, and adjustable feet for stability on uneven floors. A prominent warning label clearly marks the contents, preventing confusion and ensuring regulatory compliance.

These cabinets are perfect for settings where dangerous materials are used, providing a secure and compliant storage option. The long-lasting powder-coat finish offers superior chemical resistance inside and out. Justrite Flammable Waste Safety Cabinets are available in different setups to suit specific requirements, including manual or self-closing doors and 30 or 45-gallon sizes. Self-closing doors enhance safety by automatically closing and latching during emergencies, reducing the chance of human error and ensuring adherence to safety regulations.

Justrite Flammable Waste Safety Cabinets are FM-approved and backed by a ten-year warranty, guaranteeing reliability and peace of mind. Whether you work in a lab, factory, or chemical processing plant, these cabinets provide a versatile and compliant solution for storing hazardous waste.

Specifications

Model No	89-FW
----------	-------

Prop 65

⚠️WARNING:This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Product Options

Capacity:	30 gallon
	45 gallon
Door Style:	Self-close
	Manual

